



411 West Congress St., Maple Lake, MN 55358 Toll Free 877-466-8837

www.otteroutdoors.com

ASSEMBLY INSTRUCTIONS FOR SMALL ATV MONSTER BOX

Parts List:

Square U-Bolts (2)
Flat Strap (2)
¼" Nylock Nuts (4)

Tools Required:

Drill with 5/16" bit
Marker to layout holes
7/16" Wrench

Installation:

1. Set and square Monster Box (item 5) on rack (item 4) of ATV.
2. Layout holes (one on each side of bar) to be drilled in bottom of box, according to rack Configuration. (Best to use outside edge bars for ease of assembly).
3. Hole centers should be 1 ½" apart to fit u-bolts provided.
4. Drill 5/16 holes through the box
5. Slide U-Bolts (item 1) through box and around bar.
6. Slide Flat Strap (item 2) up on U-Bolt
7. Tighten ¼" Nylock Nuts (item 3) down to Flat Strap.

