



Installation Instructions: 201639 Pro Shelter Tray

1. Place tray in the front left corner of the sled. The edge of the tray should sit flush or just below the sled lip and against the sled front. Mark the two holes on the sled and drill out with a 9/32 or 5/16" bit.



2. Attach with the $\frac{1}{4}$ " bolts, washers and nylock nuts. Secure tray to the seat rail with the Velcro strips as shown. The tray will be right below the bolt on the seat rail.



3. Battery straps should be installed as shown. The Velcro should be on the bottom side of the strap when threading it through the slots.

